

Safety and General Information

Refer to the user manual for safety information relating to torque wrench operation, battery and battery charger before operating this equipment.

Before using battery or battery charger, read all the instructions for cautionary markings on the battery and charger. which may include a separate wall-mounted power adapter or transformer.

- *To reduce the risk of injury, use only originally provided battery, Charging dock and power adapter. Other types of batteries, battery chargers and power adapter may burst, causing personal injury and damage.
- *For indoor use only, do not put it onto fire, do not expose charger to water, rain or snow.
- *Users and bystanders must wear safety goggles.
- *Do not use it without power on.
- *Do not use the torque higher than max scale or high limit.
- *Store the equipment into box when not in use.


ELECTRONIC TORQUE WRENCH TECHNICAL DETAIL

	Torque Display Range	Torque Full Scale (FS)	Length		Weight	
			Inch	mm	Lb	g
85235 85243	2%-105%	220 lbf.in 25 N.m	15.5	394	1.74	790
85236 85244	2%-105%	240 lbf.in 28 N.m	15.5	394	1.78	810
85237 85245	2%-105%	73.8 lbf.ft 100 N.m	15.5	394	1.78	810
85238 85246	2%-105%	255 lbf.ft 340 N.m	28.5	724	3.52	1600

- * Angle Range: 0-999.9 degree with accuracy of $\pm 1\pm 1\%$ of reading
- * Torque Accuracy [20%-100%FS]: CW: $\pm 1.5\%$, CCW: $\pm 2.5\%$. Accuracy may shift 3% more in 10-20%FS, and 6% more in 5-10%FS. Flex head accuracy may shift 2% more on above.
- * Need to control angular velocity within 10° to 180° / Sec.
- * Programable Preset: 100 groups, 1-999 of job(s) for each group.
- * Data Storage: 6,000 for production mode, 2,000 for simple mode.
- * Charge and data connection: Type C port
- * Battery pack: Li-ion, 2000mAh

Charge and replace battery

The battery can be charged also by USB compatible power adapter or computer or notebook via data cable, the charging time depends on the computer or notebooks's performance. The cable is using USB type-c interface and included in the package.




Power on/off

Press and hold ROUND key for 2 seconds, the ETW will start self check and zeroing, once it's ready, it will enter previous interface.

Power off

Press ROUND key for 2 seconds, the ETW will show menu, you can press up or down key to select POWEROFF then press ROUND key to confirm.



Keys introduction

Press and hold ROUND Key for 2 seconds will

- Power on
- Go to option menu if in main interface
- Return to previous main interface when in other interfaces.

Press ROUND key will


- Confirm the choice in option menu.
- Record current DATA to memory in each main interface.
- Once record, the write icon will flash once and counter will +1.

UP/DOWN key

The ETW is menu based, when in main interface, press UP key can view history data record, press DOWN key can select options.


Reversing display

For right/left hand operation, or in some special work position.



Enable/Change Password

Press and hold ROUND key, select SETUP, select PASSWORD&ACTIVE. Change to ENABLED and then change password. When it's done, press and hold ROUND Key then select YES in SAVE SETTING interface.



- * Remember the password.
- * Entering wrong password will go back to previous interface without notification.
- * When password is enabled, user can only use UP Key to view history data, and DOWN Key to switch PEAK/TRACK/TARGET in Simple mode and Select Preset in Production mode)
- * If only P00 in system, then user will be constrained to use P00 preset.

Side LEDs indication (Torque/Angle)

Simple Mode

PEAK and TRACK: No LED indication.
TARGET: Same as Production mode below.

Production Mode


The RUNWAY light will indicate the progressing of target value. Remark: Beep and Vibration can be disabled in setup menu.

- 30%LSL/Beep
- 50%LSL/Beep
- 70%LSL/Beep
- 90%LSL/Beep
- 98%LSL/Beep&Vibration
- Within LSL and USL/Beep&Vibration
- Over USL or Overloaded/Flashing RED

Top LED indication (Torque/Angle)

Same as first of side LED indication

Simple mode interface



- * See Page10 to switch among TRACK/PEAK/TARGET in main interface.
- TRACK: real time torque or angle
- PEAK: Display Max torque or angle for 5 seconds.
- TARGET: DOWN key to change value, tolerance can be adjust in menu.
- Press UP key to view history data when in main interface. Press UP key again to quit or Press DOWN key to view earlier data.
- * When viewing data record, press ROUND key will active rework function. Rework will cover the record and marked reworked.

Simple mode setup

When in simple mode, press ROUND key for 2 seconds, select SETUP. The simple mode items will be displayed in prior.




- * Click PEAK/TRACK/TAREGT and select the items.
- TARGET Torque value's tolerance can be adjusted in this menu(1-10%).
- * UNIT selection will be effective all configuration including display. Available: N.m, lbf.in, lbf.ft, kgf.cm, kgf.m
- * Simple mode can store 2000 records.
- * HISTORY DATA will show only simple mode data.

Change the mode

Press and hold ROUND key, select SETUP then MODE OPTION.




Production mode interface



- * Press UP key to view history data when in main interface. Press UP key again to quit or Press DOWN key to view earlier data.
- * When viewing data record, press ROUND key will active rework function. Rework will cover the record and marked reworked.
- * Click DOWN key to view current PRESET detail, click UP/DOWN Key to select other PRESET.
- * Auto Record function will only record the operation that 'meet target Value' or 'over target value'. It will not record 'lower' or 'reversed' value.

Production/PRESET mode setup


Press and hold ROUND key, then select SETUP, MODIFY PRESET.




- * When move to T, and click UP/DOWN key, T or T&A mode can be selected.
- This PRESET describes that there are total 10 Presets in ETW, Preset02 requires Torque to be within 56-80lbf.in, each product will have 5 fasteners/jobs to be tighten. Angle is not required.

- * Production mode can have 100 presets, P00 is default in system. each preset can have 999 jobs. It can save 6,000 records.


Display Options




SYSTEM CONFIGURATION



OPERATION SETUP




MISC INFORMATION



CALIBRATION

Professional calibration devices is required, use only with certified testers.



Quick Tour 4-1: MODE CHANGE


Press and hold ROUND Key, then select 'SETUP' and select 'MODE OPTION', then choose 'simple mode' or 'Production mode'. And then press and hold ROUND Key again, and select 'YES'.
* Same method to change other SETUP.

Quick Tour 4-2: Use Simple Mode

Following 4-1 to use 'Simple Mode'. Then enter PEAK/TRACK/TARGET and choose TARGET 5%. Long press round Key and save setting. Click DOWN key to change TARGET value and tighten 2 or more fasteners and click ROUND Key to record for each. Press UP key to view the latest result. Press UP key again to return to main interface. Or press DOWN key to view earlier data. Press UP key then press ROUND Key, it will show rework function.

Quick Tour 4-3: PRESET in Production Mode

Following 4-1, change to 'Production Mode', Press DOWN key to view current PRESET. Press and hold ROUND Key, Select 'SETUP', then select 'Modify Preset'. Try to modify blue box content.




Quick Tour 4-3: Use Production Mode

Following 4-1, change to 'Production Mode', Press DOWN key to view current PRESET. Or press UP or DOWN Key to other PRESET. Then press ROUND Key. Try to use the PRESET to tightening a fastener and press ROUND Key to record. Then press UP Key to view the data, press ROUND Key to active 'Rework' and select 'YES', then redo tightening and record. R will show after #jobs.

Data Management Software.

Coming Soon!

Connect ETW and Computer with Type-C data cable, the USB icon will appear. Run software, and operate from computer to get data etc.



Apex Tool Group, LLC
1000 Lufkin Road, Apex, NC 27539
www.apextoolgroup.com
©2020 Apex Tool Group, LLC
GEARWRENCH® is registered as a trademark of Apex Brands, Inc., a Division of ApexToolGroup, LLC

