


CORNERSTONE VR: PICO G2 4K SETUP GUIDE




This document will guide you through the setup process of a brand new Pico G2 4K (this document will be updated with pictures as soon as possible).

1. **Unpack the Pico G2 4K headset. Remove the cellophane, remove all of the attached tape and cellophane, and remove the lens covers.**
2. **Unpack the Pico Motion Controller. The small white box behind the headset houses the Controller, 2xAAA batteries, a USB-C charging cable, a USB-Wall Outlet brick and a Lens cloth.**
3. **Insert the AAA batteries into the Controller by removing the plastic battery cover on the back, which slides down.**
4. **Switch on the headset by holding down the power button on the bottom of the headset.**
5. **Once the headset has switched on fully, you must follow the on-screen instructions to connect to the headset to your WiFi. Please note: when typing with the Pico headset (like typing your WiFi password), be sure to click the ↵/Enter key at the bottom right of the keyboard before selecting Confirm.**
6. **Continue to follow the on-screen instructions to connect the controller (by pressing the PICO button on the controller, waiting for it to connect, then hold it down).**
7. **Once you find yourself in the Pico home screen, please look to the right and select 'System Update'.**



8. **Now select 'Check for Updates'” You will now be shown a list of features in the latest update, select 'Update Now'. The update will now download, this will take 2-7 minutes (depending on your internet speed).**
9. **Once this is downloaded, the headset will check to see if the device is charged. Please select 'Update Now', if the headset battery is below 40%, it will refuse to do this. In this case, please charge your headset, then repeat this step.**


10. Once the headset has completed the update install (which can take up to 20 minutes), we are ready to install the Antser application.
11. First of all, download the “v0.4” file from Dropbox (or wherever it is being hosted, if you are unsure, please contact us to email this file to you).
12. Unzip the file by right-clicking, and selecting ‘Extract’.
13. A new folder will be created called “v0.4”, enter this folder.
14. Plug your switched-on Pico headset into your PC via USB.
15. Wait approximately 15 seconds to ensure it is connected and recognised, then double click the file ‘install(Windows)’.
16. A black command-prompt window will appear on-screen. After approximately 30 seconds you should see the word “Success!” followed by “Press any key to continue...”.
17. Press any key and the window will disappear, the application is installed!
18. Back to the headset, put it on.
19. Head into ‘Settings’ by selecting the Settings Icon at the top of the home screen.



20. On the far right, select ‘About’.
21. In the centre of the screen, the top setting will be ‘PUI version’. Click on this setting 5 times and Developer mode will be unlocked.
22. On the far right, you will now see Advanced Settings. Select this.
23. Scroll down to ‘System’ and select it.
24. Scroll down to ‘Developer Options’.
25. Scroll down until you find ‘Special Settings’ (this is quite far down the menu).
26. Under ‘Special Settings’, you will find ‘auto-sleep’. Turn the setting off.

27. Now press the Pico button to return to the main menu.

28. On the far right of the menu, where you saw 'System Update', you will now see "Antser" (or "Vroadcaster"). Select this.



29. Select this application and it will ask you for various permissions, click 'allow' for all of them.

30. Now the app will start to download the content automatically, it will begin downloading 58 files.

31. This can take up to 2 hours dependent on your internet speed.

32. Once this is complete, you will be inside the Antser app, ready to use.

